

SG7

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL INTECH/ALCO SENSOR IV	PAS SERIAL NO. 000074
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	TEMP		TEST #1 (Optional)	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1544 34		17AP41035		.100	21					X		Lee	17046	
			Solution prepared by:												
			Cesar A. Mejia												
			Date: 01-09-17												
			Expiration date:												
			01-09-19												

04/09/18 15:47
AS4 Serial no: 0088074
Version no: 4797

No. Date Time ZBAC
Calibration
10/24/17 11:04 .100

Test Result

0001	03/31/18	22:37	.082
0002	03/31/18	22:41	.078
0003	03/31/18	22:48	.000
0004	04/07/18	02:31	.000
0005	04/07/18	02:34	.000
0006	04/03/18	20:46	.289
0007	04/03/18	20:49	.288
0008	04/05/18	02:11	.136
0009	04/05/18	02:14	.131
0010	04/08/18	03:12	.107
0011	04/08/18	03:15	.103
0012	04/09/18	15:46	.098

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
 DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
 CHP 202K (Rev. 8-08) OPI 051

#1

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16120188
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP #1	TEMP #2 (Optional)		TEST #1	TEST #2 (Optional)	YES	NO	YES	NO				
04/09/2018	12:55:34		17AP41035		.100	22							Lee	17046	

Solution prepared by:

Cesar A. Mejia

Date: 01-09-17

Expiration date:

01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16120188
UOM	BAC
Last Check	04/09/2018
Time:	12:54 PM
Cal Standard	.100
Result	.096
Last Cal	10/21/2016
Time:	08:16 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of

** If using dry gas for accuracy checks, note the canister set to 0.110).

#2

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	ID. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16120194
--------------------------------	-----------------	------------------------------	---------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**	VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
					TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1303	34	17AP41035	.100	21		.097					Lee	17046	

Solution prepared by:

Cesar A. Mejia

Date: 01-09-17

Expiration date:

01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16120194
UOM	BAC
Last Check	04/09/2018
Time:	1:00 PM
Cal Standard	.100
Result	.097
Last Cal	01/29/2018
Time:	08:50 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

to 0.110).

#4

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16120195
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1307	34	17AP41035	.100	22	106				X	Lee	17046	

Solution prepared by:
 Cesar A. Mejia
 Date: 01-09-17
 Expiration date:
 01-09-19

Lifeloc Technologies

Calibration / Check Printout

FC20	8.7.24
Serial No.	16120195
UOM	BAC
Last Check	04/09/2018
Time:	1:07 PM
Cal Standard	.100
Result	.106
Last Cal	04/25/2017
Time:	08:47 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
 DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
 CHP 202K (Rev. 8-08) OPI 051

#6

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16040161
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1321	34	17AP41035	.100	22	TEST #1	TEST #2				Lee	17046	

Solution prepared by:
 Cesar A. Mejia
 Date: 01-09-17
 Expiration date:
 01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16040161
UOM	BAC
Last Check	04/09/2018
Time:	1:25 PM
Cal Standard	.100
Result	.104
Last Cal	04/25/2017
Time:	08:56 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the act
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#7

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifoloc/FC20	PAS SERIAL NO. 16040140
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	LOT NO.	VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
					TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1325	31	17AP41035	.100	22						X	Lee	17046	

Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19														
Lifoloc Technologies														
Calibration / Check Printout														
FC20					8.7.24									
Serial No.					16040140									
UOM					BAC									
Last Check					04/09/2018									
Time:					1:24 PM									
Cal Standard					.100									
Result					.104									
Last Cal					04/25/2017									
Time:					08:58 AM									
Cal Standard					.100									

* If the reading is within plus or minus (±) 0.010 percent of the au
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
 DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
 CHP 202K (Rev. 8-08) OPI051

#22

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16040162
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (#1)	TEMP (#2)		TEST #1	TEST #2 (Optional)	YES	NO	YES	NO				
04/09/2018	1400	34	17AP41035		.100	23							Lee	17046	

Solution prepared by:
 Cesar A. Mejia
 Date: 01-09-17
 Expiration date:
 01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16040162
UOM	BAC
Last Check	04/09/2018
Time:	2:05 PM
Cal Standard	.100
Result	.097
Last Cal	08/14/2017
Time:	10:14 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the simulator.
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#23

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifoloc/FC20	PAS SERIAL NO. 16120177
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1440	34	17AP41035	.100	23	.104				X	Lee	17046	

Solution prepared by:

Cesar A. Mejia

Date: 01-09-17

Expiration date:

01-09-19

Lifoloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16120177
UOM	BAC
Last Check	04/09/2018
Time:	2:08 PM
Cal Standard	.100
Result	.104
Last Cal	04/25/2017
Time:	09:50 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol simulator, no further action is required.
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
 DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
 CHP 202K (Rev. 8-08) OPI 051

#26
 16080065

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	ID. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16080065
--------------------------------	-----------------	------------------------------	---------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1415	34	17AP41035		.100	22		105			X		Lee	17046	

Solution prepared by:

Cesar A. Mejia

Date: 01-09-17

Expiration date:

01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16080065
UOM	BAC
Last Check	04/09/2018
Time:	2:17 PM
Cal Standard	.100
Result	.105
Last Cal	12/19/2017
Time:	1:54 PM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the accuracy.

** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#32

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16080071
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1433	34	17AP41035	.100	23	101					Lee	17046	

Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19	
Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16080071
UOM	BAC
Last Check	04/09/2018
Time:	2:33 PM
Cal Standard	.100
Result	.101
Last Cal	08/14/2017
Time:	10:41 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the ac
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#34

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16040163
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1504	34	17AP41035	.100	24	.095			X		Lee	17046	

Solution prepared by:

Cesar A. Mejia

Date: 01-09-17

Expiration date:

01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16040163
UOM	BAC
Last Check	04/09/2018
Time:	3:02 PM
Cal Standard	.100
Result	.095
Last Cal	06/07/2017
Time:	11:02 AM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the

** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#39
 16080072

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO.
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1518	34	17AP41035	.100	22	103				X	Lee	17046	

Solution prepared by:
 Cesar A. Mejia
 Date: 01-09-17
 Expiration date:
 01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16080072
UOM	BAC
Last Check	04/09/2018
Time:	3:21 PM
Cal Standard	.100
Result	.103
Last Cal	12/19/2017
Time:	2:05 PM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of t
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
 DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
 CHP 202K (Rev. 8-08) OPI 051

#46

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL LIFELoc FC20	PAS SERIAL NO. 16120189
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1534	34	17AP41035	.100	23						K. Lee	17046	

Solution prepared by:
 Cesar A. Mejia
 Date: 01-09-17
 Expiration date:
 01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16120189
UOM	BAC
Last Check	04/09/2018
Time:	3:33 PM
Cal Standard	.100
Result	.097
Last Cal	09/01/2017
Time:	12:17 PM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

52

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 14080013
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	154034	17AP41035	.100		23	TEST #1	TEST #2 (Optional)				Lee	17046	

Solution prepared by:
Cesar A. Mejia
Date: 01-09-17
Expiration date:
01-09-19

Lifeloc Technologies	
Calibration / Check Printout	
FC20	8.7.24
Serial No.	16080013
UOM	BAC
Last Check	04/09/2018
Time:	3:41 PM
Cal Standard	.100
Result	.100
Last Cal	01/29/2018
Time:	12:59 PM
Cal Standard	.100

* If the reading is within plus or minus (±) 0.010 percent of the accuracy range, the calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG

#3

CHP 202K (Rev. 8-08) OPI 051

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Lifeloc/FC20	PAS SERIAL NO. 16120197
--------------------------------	-----------------	------------------------------	----------------------	--------------------------------	----------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1 (Optional)	TEST #2 (Optional)	TEST #1 (Optional)	TEST #2 (Optional)	YES				
04/09/2018			17AP41035	.100							Lee	17046	NOT IN locker

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#5

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 008559
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
				TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1315	34	17AP41035	20		.100	.100		X		K. Lee	17046	
			Solution prepared by:										
			Cesar A. Mejia										
			Date: 01-09-17										
			Expiration date:										
			01-09-19										

04/09/18 13:28
AS4 Serial no: 008559
Version no: 4797

No. Date Time XBAC
Calibration
01/15/16 10:40 .100

Test Result
0001 04/09/18 13:17 .100

Push No. 3 to erase.

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

8

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 008620
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**			PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1327	34	17AP41035	.100	20	106				X		K. Lee	17046	

or Power down to retain

04/09/18 13:31
AS4 Serial no: 008620
Version no: 4797

No. Date Time KBAC
Calibration
01/15/16 11:10 .100

Test Result
0001 04/09/18 13:30 .106

Push No. 3 to erase.

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).

** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#10

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 077505
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMPERATURE		SIMULATOR SOLUTION (OR DRY GAS)**	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	13:31	34	17AP41035	VALUE	TEST #1	TEST #2						K. Lee	17046	
				.100	21		.100			X				
				Solution prepared by:										
				Cesar A. Mejia										
				Date: 01-09-17										
				Expiration date:										
				01-09-19										

```

or power down to retain
_____  

04/09/18 13:33  

AS4 Serial no: 077505  

Version no: 4797

No. Date Time XBAC  

Calibration  

01/18/18 10:56 .100

Test Result  

0001 04/09/18 13:32 .100
_____  

Push No. 3 to erase,  

or power down to retain
_____
    
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#12

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 082653
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE		TEST #1 (Optional)	TEST #2 (Optional)	YES	NO				
04/09/2018	1334	34	17AP41035	.100	TEST #1 20	TEST #2 (Optional)	TEST #1 .104	TEST #2 (Optional)			K. Lee	17046	
			Solution prepared by: Cesar A. Mejia										
			Date: 01-09-17										
			Expiration date: 01-09-19										

```

04/09/18 13:33
AS4 Serial no: 082653
Version no: 4797

No. Date Time ZBAC
Calibration
02/11/16 10:14 .100

Test Result
0001 04/09/18 13:32 .104

Push No. 3 to erase,
or power down to retain
    
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#13

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 008709
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1 (Optional)	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1335	34	17AP41035	.100	21	.106				X	K. Lee	17046	
			Solution prepared by: Cesar A. Mejia										
			Date: 01-09-17										
			Expiration date: 01-09-19										

```

04/09/18 13:36
AS4 Serial no: 008709
Version no: 4797

No. Date Time XBAC
Calibration
03/17/16 09:40 .100

Test Result
0001 04/02/18 00:50 .162
0002 04/02/18 00:52 .158
0003 04/09/18 13:36 .106

Push No. 3 to erase,
or power down to retain
    
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#14

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 008714
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1337	34	17AP41035	.100	21	.103					K. Lee	17046	
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19										

```

04/09/18 13:40
AS4 Serial no: 008714
Version      not 4797

No.  Date   Time  XBAC
Calibration
    05/14/17 09:50 .100

Test Result
0001 04/09/18 13:39 .103

Push No. 3 to erase,
or power down to retain
    
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#16

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/COMMENTS
			TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1339	34	17AP41035	.100	21	.107	X				K. Lee	17046		
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19											
<pre> 04/09/18 13:39 AS4 Serial no: 008898 Version no: 4797 No. Date Time ZBAC Calibration 03/17/16 09:44 .188 Test Result 0001 04/05/18 21:33 .027 0002 04/09/18 13:38 .107 </pre>														

PAS MAKE/MODEL
Intoximeters/Alco-Sensor IV

I.D. NUMBER
17046

COORDINATOR NAME
Kirk Lee

AREA NO.
530

PAS SERIAL NO.
008888

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG

CHP 202K (Rev. 8-08) OPI051

#17

AREA NAME: South Los Angeles
 AREA NO: 530
 COORDINATOR NAME: Kirk Lee
 I.D. NUMBER: 17046
 PAS MAKE/MODEL: Intoximeters/Alco-Sensor IV
 PAS SERIAL NO.: 008783

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1340	34	17AP41035	.100	22	102	X				K. Lee	17046		
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19											
			Push No. 3 to erase, or power down to retain											
			No. Date Time ZBAC Calibration 05/14/17 10:07 .100											
			Test Result 0001 04/01/18 22:48 .000 0002 04/07/18 22:19 .216 0003 04/07/18 22:22 .217 0004 04/08/18 02:09 .120 0005 04/08/18 02:12 .111 0006 04/09/18 13:44 .102											
			Push No. 3 to erase, or power down to retain											

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).

** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
 DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
 CHP 202K (Rev. 8-08) OPI051

#18

AREA NAME: South Los Angeles
 AREA NO.: 530
 COORDINATOR NAME: Kirk Lee
 I.D. NUMBER: 17046
 PAS MAKE/MODEL: Intoximeters/Alco-Sensor IV
 PAS SERIAL NO.: 082657

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**			PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	CALIBRATION REQUIRED					
									YES	NO				
04/09/2018	1346 34	17AP41035		.100	21		.100			X		K. Lee	17046	
		Solution prepared by:												
		Cesar A. Mejia												
		Date: 01-09-17												
		Expiration date:												
		01-09-19												

04/09/18 13:48
 AS4 Serial no: 082657
 Version no: 4797

No. Date Time XBAC
 Calibration
 05/21/17 08:18 .100

Test Result
 0001 04/09/18 13:47 .100

Push No. 3 to erase,
 or power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#19

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 008810
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/COMMENTS
			LOT NO.	VALUE		TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1424	34	17AP41035	.100	35	TEST #1	TEST #2			X	K. Lee	17046	
			Solution prepared by: Cesar A. Mejia										
			Date: 01-09-17										
			Expiration date: 01-09-19										

04/09/18 14:27
AS4 Serial no: 008810
Version no: 4797

No. Date Time ZBAC
Calibration
05/21/17 08:20 .100

Test Result
0001 04/09/18 14:27 .099

Push No. 3 to erase,
or Power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#20

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 018684
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1401	34	17AP41035	.100	20	.100					K. Lee	17046	
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19										

04/09/18 14:05
 AS4 Serial no: 018684
 Version no: 4797

No. Date Time ZBAC
 Calibration
 01/12/16 14:36 .093

Test Result
 0001 04/09/18 14:04 .106

Push No. 3 to erase,
 or Power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#21

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 008635
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS	
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES					NO
04/09/2018	1404	39	17AP41035	.100	21					X		K. Lee	17046	
			Solution prepared by:											
			Cesar A. Mejia											
			Date: 01-09-17											
			Expiration date:											
			01-09-19											

04/09/18 14:05
 AS4 Serial no: 008635
 Version no: 4797

No. Date Time %BAC
 Calibration
 05/21/17 08:23 .100

Test Result
 0001 04/01/18 22:08 .293
 0002 04/01/18 22:12 .289
 0003 04/08/18 03:08 .116
 0004 04/08/18 03:11 .117
 0005 04/08/18 22:23 .112
 0006 04/08/18 22:25 .118
 0007 04/09/18 14:04 .104

Push No. 3 to erase,
 or power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#24
 008848

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO.
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	----------------

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1412	34	17AP41035	.100	20	.104				X	K. Lee	17046	
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19										
<pre> 04/09/18 13:15 AS4 Serial no: 008848 Version no: 4797 No. Date Time ZPAC Calibration 05/21/17 08:30 .100 Test Result 0001 04/09/18 13:14 .104 Push No. 3 to erase, or power down to retain </pre>													

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG

#25

CHP 202K (Rev. 8-08) OPI 051

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 077591
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS	
		TEMP (°C)	LOT NO.		TEST #1	TEST #2 (Optional)	YES	NO					
04/09/2018	1415	34	17AP41035	20		.104			X		K. Lee	17046	
			Solution prepared by:										
			Cesar A. Mejia										
			Date: 01-09-17										
			Expiration date:										
			01-09-19										

```

04/09/18 14:16
AS4 Serial no: 077591
Version no: 4797

No.   Date   Time   ZRAC
Calibration
      05/21/17 08:35 .100

Test Result
0001 04/09/18 14:15 .104

Push No. 3 to erase,
or power down to retain
  
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#27

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/A.lco-Sensor IV	PAS SERIAL NO. 077573
--------------------------------	-----------------	------------------------------	----------------------	------------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS	
			LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO					
04/09/2018	1416	34	17AP41035	.100	22	.097			X			K. Lee	17046		
			Solution prepared by:												
			Cesar A. Mejia												
			Date: 01-09-17												
			Expiration date:												
			01-09-19												
			<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Test Result</p> <p>0001 04/09/18 14:21 .097</p> <hr/> <p>Calibration</p> <p>01/18/18 11:23 .100</p> <p>No. Date Time XBAC</p> </div> <div style="width: 45%;"> <p>04/09/18 14:21</p> <p>AS4 Serial no: 077573</p> <p>Version no: 4797</p> <hr/> <p>Push No. 3 to erase.</p> </div> </div>												

* If the reading is within plus or minus (\pm) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#28

083051

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	ID. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO.
--------------------------------	-----------------	------------------------------	---------------------	-----------------------------------------------	----------------

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		VALUE	PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS	
			LOT NO.	TEMP		TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO					
04/09/2018	1422	34	17AP41035		.100	21			99		X		K. Lee	17046		
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19													

04/09/18 14:22
AS4 Serial no: 083051
Version no: 4797

No. Date Time ZBAC
Calibration
12/28/17 13:29 .100

Test Result
0001 04/09/18 14:22 .097

Push No. 3 to erase,
or Power down to retain

or power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#30
008897

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO.
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	----------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1426 34	17AP41035	.100	20	105				X		K. Lee	17046	
		Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19											
		Push No. 3 to erase, or power down to retain											
		Test Result 0001 04/09/18 14:28 .105											
		No. Date Time ZBAC Calibration 01/18/12 16:13 .100											
		04/09/18 14:29 A84 Serial no: 008897 Version no: 4797											

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

STATE OF CALIFORNIA
DEPARTMENT OF CALIFORNIA HIGHWAY PATROL
PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG
CHP 202K (Rev. 8-08) OPI 051

#31

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/AIco-Sensor IV	PAS SERIAL NO. 018624
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1428	34	17AP41035	.100	22					X		K. Lee	17046	
			Solution prepared by: Cesar A. Mejia											
			Date: 01-09-17											
			Expiration date: 01-09-19											

```

04/09/18 14:31
AS4 Serial no: 018624
Version no: 4797

No. Date Time ZBAC
Calibration
02/01/16 11:02 .100

Test Result
0001 04/09/18 14:31 .103

Push No. 3 to erase,
or power down to retain
  
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

33

AREA NAME	AREA NO.	COORDINATOR NAME	I.D. NUMBER	PAS MAKE/MODEL	PAS SERIAL NO.
South Los Angeles	530	Kirk Lee	17046	Intoximeters/Alco-Sensor IV	077488

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)	PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/COMMENTS
		TEMP (°C)	LOT NO.		VALUE	TEST #1 (Optional)	TEST #2 (Optional)	YES				
04/09/2018	1435	34	17AP41035	.100	TEST #1: 21	TEST #2: .105				K. Lee	17046	

```

04/09/18 14:37
AS4 Serial no: 077488
Version no: 4797

No.   Date   Time   XBAC
Calibration
    02/11/16 10:52 .100

Test Result
0001 04/09/18 14:34 .105

Push No. 3 to erase.
    
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG

#34

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/A.lco-Sensor IV	PAS SERIAL NO. 008877
--------------------------------	-----------------	------------------------------	----------------------	------------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED	PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1 (Optional)	TEST #2 (Optional)	YES					
04/09/2018		17AP41035	.100							K. Lee	17046	NOT IN LOCKER
		Solution prepared by:										
		Cesar A. Mejia										
		Date: 01-09-17										
		Expiration date:										
		01-09-19										

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
 ** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

37

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 018626
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME (^h : ^{mm} : ^{ss})	TEMP (°C)	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
			LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES	NO				
04/09/2018	1500	34	17AP41035	.100	21		.102		X		K. Lee	17046		
			Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19											

```

or power down to retain

04/09/18 15:07
AS4 Serial no: 018626
Version no: 4797

No. Date Time XBAC
Calibration
07/15/16 15:21 .100

Test Result
0001 04/09/18 15:06 .102

Push No. 3 to erase,
or Power down to retain
  
```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

39

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 003030
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1520	34	17AP41035	.100	22	.097				X	K. Lee	17046	
			Solution prepared by:										
			Cesar A. Mejia										
			Date: 01-09-17										
			Expiration date:										
			01-09-19										

04/09/18 15:20
AS4 Serial no: 083030
Version no: 4797

No. Date Time XBAC
Calibration
12/28/17 13:51 .100

Test Result
0001 04/09/18 15:19 .097

Push No. 3 to erase,
or power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PRELIMINARY ALCOHOL SCREENING (PAS) DEVICE ACCURACY CHECK/CALIBRATION LOG

CHP 202K (Rev. 8-08) OPI 051

#40

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO.
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	----------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED	PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)					
04/09/2018	1521 34		17AP41035							K. Lee	17046	
		Solution prepared by: Cesar A. Mejia Date: 01-09-17 Expiration date: 01-09-19										

04/09/18 15:23
 ASA Serial no: 018692
 Version no: 4797

No. Date Time XBAC
 Calibration
 02/01/16 11:30 .100

Test Result
 0001 04/09/18 15:21 .100

Push No. 3 to erase,
 or power down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).

** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

#42

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	I.D. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 018762
--------------------------------	-----------------	------------------------------	----------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1525	34	17AP41035	.100	22	096			X		K. Lee	17046	

04/09/18 15:26
AS4 Serial no: 018762
Version no: 4797

No. Date Time XBAR
Calibration
12/28/17 14:01 .100

Test Result
0001 03/31/18 00:13 .004
0002 03/31/18 00:16 .004
0003 03/31/18 04:01 .067
0004 03/31/18 04:05 .068
0005 04/01/18 01:05 .229
0006 04/01/18 01:09 .225
0007 04/05/18 00:25 .137
0008 04/05/18 00:28 .138
0009 04/06/18 02:07 .151
0010 04/06/18 02:09 .147
0011 04/09/18 15:26 .096

Push No. 3 to erase,
or POWER down to retain

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

#51

AREA NAME South Los Angeles	AREA NO. 530	COORDINATOR NAME Kirk Lee	ID. NUMBER 17046	PAS MAKE/MODEL Intoximeters/Alco-Sensor IV	PAS SERIAL NO. 041495
--------------------------------	-----------------	------------------------------	---------------------	-----------------------------------------------	--------------------------

PAS DEVICES SHALL BE CHECKED FOR ACCURACY EVERY 10 DAYS OR EVERY 150 TESTS, WHICHEVER OCCURS FIRST.

DATE	TIME	SIMULATOR SOLUTION (OR DRY GAS)**		PAS TEMP (°C)		PAS ACCURACY CHECK RESULTS*		CALIBRATION REQUIRED		PAS RETEST RESULTS	OPERATOR	I.D. NO.	REPAIRS/PROBLEMS/ COMMENTS
		TEMP (°C)	LOT NO.	VALUE	TEST #1	TEST #2 (Optional)	TEST #1	TEST #2 (Optional)	YES				
04/09/2018	1530	34	17AP41035	.100	21	.098				X	K. Lee	17046	

```

04/09/18 15:38
AS4 Serial no: 041495
Version no: 4797

No. Date Time ZBAC
Calibration
12/28/17 14:18 .100

Test Result
0001 04/09/18 15:38 .098

Push No. 3 to erase,
or power down to retain

```

* If the reading is within plus or minus (±) 0.010 percent of the actual value of the alcohol solution, no calibration is required (e.g., with a 0.100 percent solution, an acceptable range is 0.090 to 0.110).
** If using dry gas for accuracy checks, note the canister serial number in the lot no. column. If needed, calibration shall be performed with a wet bath simulator.

